










<p><b>1</b> You need: Siderise Foil Tape RFT120/45, Suitable non-combustible fixings with a washer 10-15mm in diameter and spiral screws supplied by contractor.</p>	<p><b>2</b> Cutting on site – tools required: marker, tape measure, knife and saw.</p>	<p><b>3</b> Cutting on site – measure the cover area size and mark on the foil facing your cut line.</p>	<p><b>4</b> Cutting on site – Use a sharp knife to cut through the foil facings on both sides.</p>	<p><b>5</b> Cutting on site – Cut the stonewool with a saw, being careful not to rip the foil facing.</p>
				
<p><b>6</b> Line up the board against the back of the façade checking the full area is covered.</p>	<p><b>7</b> Use non-combustible fixings with a washer 10-15mm in diameter to fix the board to the façade; 6-7 number per m<sup>2</sup>.</p>	<p><b>8</b> Line up the next board tightly abutting the previous and fix to the façade.</p>	<p><b>9</b> Using Siderise Foil Tape RFT120/45, tape the abutting joints between boards.</p>	<p><b>10</b> Using Siderise Foil Tape RFT120/45, tape any exposed screw heads and washers.</p>
				
<p><b>11</b> Using Siderise Foil Tape RFT120/45, tape the exposed stonewool edges of the boards.</p>	<p><b>12</b> If installing a second layer, ignore steps 10-11. Line up the second layer board staggering abutting joints.</p>	<p><b>13</b> Fix the second boards to the first using spiral screws.</p>	<p><b>14</b> Using Siderise Foil Tape RFT120/45, tape abutting joints between boards, exposed screw heads and exposed stonewool edges as per steps 9-11.</p>	<p><b>15</b> Siderise Firestop can now be installed between the structure and the protected spandrel.</p>